

# DEFY WOOD BRIGHTENER

## PRODUCT DATA

### DEFY Wood Brightener

**MANUFACTURER:** SaverSystems

Richmond, IN 47374

800-860-6327

Fax 765-935-4999

www.saversystems.com

## DESCRIPTION

**DEFY Wood Brightener** is a liquid concentrate that is mixed with water to brighten and restore the natural beauty of exterior wood. It removes tannin and rust stains and is recommended for use on all species of wood, including redwood. DEFY Wood Brightener will not harm wood fibers, grass or most plants when used properly.

## USES

DEFY Wood Brightener removes dirt, grime, tannin, rust, and fungi stains from horizontal and vertical wood surfaces. DEFY Wood Brightener is recommended for surface preparation prior to initial application of clear finishes and stains. It is used as a neutralizer and brightener for all wood species that have been cleaned with **DEFY Wood Cleaner**. For best results use SaverSystems water repellent wood finishes.

**Note:** DEFY Wood Brightener is not formulated to remove intact paint, stain, or clear finishes and may dull painted and metal surfaces if not quickly rinsed.

## BENEFITS

- Restores the rich look of new wood
- Won't harm most plants or shrubbery
- Will restore redwood or cedar that has been darkened in the cleaning process to its original color

## DIRECTIONS FOR USE

**Step 1: MIX:** Shake DEFY Wood Brightener to thoroughly mix. Dilute 1 part DEFY Wood Brightener to 4 parts water in a plastic container and mix well.

**Step 2: APPLY:** Thoroughly wet surface and ALL surrounding vegetation with water before application. Apply DEFY Wood Brightener solution to wet wood with sprayer, brush, or mop. Let solution stand for 3-5 minutes, keeping wet with additional solution if necessary. On vertical surfaces begin applying solution at the bottom and work to the top. Application may be repeated if desired.

**Step 3: RINSE:** Rinse wood and all surrounding vegetation thoroughly by flooding area with water from garden hose. Rinse vertical surfaces from bottom up to avoid streaking.

**COVERAGE:** 100 - 200 sq. ft. per gallon, depending on wood porosity, when mixed at the recommended dilution rate of 1 part DEFY Wood Brightener to 4 parts water by volume.

## CAUTIONS

**Keep out of reach of children!** Do not take internally. Avoid contact with eyes and skin. Avoid breathing mist. Close container tightly after each use. Do not re-use containers.

Contains oxalic acid. Do not mix DEFY Wood Brightener with DEFY Wood Cleaner, chlorine bleach or other chemicals. Store in original container only. Keep from freezing. The use of chemical splash goggles and rubber gloves is recommended when handling this product. Accumulation of product on ladders, scaffolding, decks, etc. may result in a slippery surface.

**FIRST AID:** In case of eye contact, flush immediately with water for 15 minutes. Get prompt medical attention. In case of skin contact, rinse with water. If swallowed, give milk or water, do not induce vomiting. Call physician.

## LIMITED WARRANTY

SaverSystems warrants this product to be free from defects for six months from date of purchase. Any claim must be made in writing, accompanied by proof of purchase. We will only be obligated to replace the product or refund the purchase price. There is no other express warranty.

SaverSystems shall not be liable for incidental or consequential damages resulting from any breach of this warranty and fitness for use. Some states do not allow the exclusion of incidental or consequential

damages, so the above warranty may not apply to you. This warranty gives you specific legal rights. You may also have other rights, which vary, from state to state.

## PACKAGING

DEFY Wood Brightener is available in 1 gallon recyclable plastic containers. One gallon of concentrate will make 5 gallons of DEFY Wood Brightener.

## TRANSPORT AND STORAGE

DEFY Wood Brightener is not considered hazardous under Department of Transportation regulations. Store in cool, dry area. Keep from freezing.